


# INSTALLATION INSTRUCTION


**VENTAFLEX®**

More efficiency in air conduction

Air duct Ø 200-1250 mm



VentaFix



VentaSnap, Supplies



## VENTAFLEX® AIR DUCT ROUND

### Responsibility

The installation instruction for VENTAFLEX® products are a non-binding recommendation which is not legally binding. They are based on construction data and installation experience. An overall responsibility for the system on the part of VENTAFLEX® is not possible, because it solely develops, produces and delivers components and modules for the preparation of ventilation- and heating systems.

**Please read this installation instruction carefully before starting the installation und make sure that all necessary materials and tools are ready to be used.**



**The employer or self-employed person has to make sure that industrial or commercial users of diisocyanate have completed a training for the secure use of it.**

### Safety note

Installation work may only be done by skilled workers who have sufficient knowledge in

- safety regulations
- accident prevention regulations
- guidelines and recognized rules of the technology (e.g. VDE-provisions, DIN-standards)

because of their professional training, experience und instruction.

The skilled workers must

- be able to assess the assigned work, recognize possible dangers and avoid them
- be authorized to carry out the necessary work and action by those responsible for safety of the plant.


### Quick help

If you have any further questions regarding the installation or other VENTAFLEX® products, please contact our hotline or call us under **+49 (0) 25 05 - 93 829 -20**. We will now lead you through the installation step by step.



You find further generally valid information about the processing of VENTAFLEX® air ducts under **[www.ventaflex.de](http://www.ventaflex.de)**

Content	Page
<b>VentaSnap</b>	<b>2.29</b>
<b>VentaSnap and glue</b>	<b>2.30</b>
<b>VentaFix</b>	<b>2.31</b>
<b>Roof duct</b>	<b>2.32</b>
<b>Length adjustment</b>	<b>2.33</b>
<b>Compensator</b>	<b>2.34</b>
<b>Transition duct systems</b>	<b>2.35</b>

## Structure of the VentaSnap clamp





## Handling VentaSnap



A VentaSnap clamp is pushed over the VENTAFLEX® air duct. Put a second duct on top of the first one and adjust it so that groove and tongue are joined.

**Tip:**  
Soap can be used to make the pushing easier.



Pull the VentaSnap clamp centered over the connection and screw it together.


After this process step we recommend doing a tightness test.

We recommend considering when planning that VENTAFLEX® air duct in components is available with a length of 3 m. This way unnecessary installation effort can possibly be avoided.

Depending on the application area of the duct the sole use of the VentaSnap clamp is enough. However we generally recommend to combine the adhesion with the VentaSnap clamp.

In the hygiene sector this is mandatory.

### Information about VentaRapid






VentaRapid is a special glue for PUR rigid foam. Ideal results are reached at a processing temperature of 5°C to 35°C.

Skin building time is after approx. 30 min. Indications of quantity are found on the cartridge.

#### Tip:




At low ambient temperature the flowability can be improved by placing the cartridges in a bucket of warm water before handling them or in heated room for storage.

### Handling of VentaSnap + glue



A VentaSnap clamp is pushed over the VENTAFLEX® air duct.

Apply the glue circular in three rings. Attention must be paid that all adhesive- and seal surfaces must be freed from dust, grease and other deposits.



The second duct is put on top of the first one until groove and tongue are joined. Spread the glue with pressure by moving the ducts back and forth, subsequently seal the adhesive seam with glue from the outside.


Glue the enclosed Armaflex-Pad on the seam. Pull the VentaSnap clamp centered over the connection and pad and screw it together.

After 12 hours of setting time the glue is hardened.


After this process step we recommend doing a tightness test.

Upon request we additionally offer a tightness test for your special project with VENTAFLEX® air ducts.


### Structure of the VentaFix clamp



### Handling VentaFix




Put the components on the lower VentaFix clamp parts. After that connect the duct segments with a VentaSnap clamp as described.



Following that put down the upper VentaFix clamp and screw it together.

**Washed concrete slabs as foundation for the construction avoids the penetration of the roof membrane. We recommend individually reconciling a possible wind load.**

**The distance between two VentaFix clamps should not exceed 3 m.**



1


Make roof cut-out

2

Place VENTAFLEX® - roof duct centered on the opening of the roof membrane, push it through the opening and connect it with the roof membrane generously.


3

Connect the duct segments as shown (see „Installation VentaSnap + adhesion“).




If required VENTAFLEX® produces a roof duct according to the angle of the roof inclination

### Generation of exact duct length




Remove groove or tongue at the connection point of the VENTAFLEX® air duct with a jigsaw.

**Tip:**  
We recommend to cut the VENTAFLEX® air duct with a jigsaw with a metal saw blade.




Push a VentaSnap clamp as a stop on the VENTAFLEX® air duct which is to be shortened and tighten it slightly. After that shorten the VENTAFLEX® air duct with the jigsaw.



Apply plenty of glue on the cutting point after shortening (see „Installation VentaSnap + adhesion“). Put both VENTAFLEX® air ducts up to contact and spread the glue with pressure by moving the ducts back and forth.  
Finally pull the VentaSnap clamp centered over the connection and screw it together.


### Installation of a compensator for the expansion compensation




Remove groove or tongue at the connection point of the VENTAFLEX® air duct with a jigsaw, between which the compensator should be inserted.

#### Tip:

We recommend to cut the VENTAFLEX® air duct with a jigsaw with a metal saw blade.



After pushing two VentaSnap clamps on the ends of the VENTAFLEX® air ducts, fit in the compensator between the two cutting points.




Apply plenty of glue on the cutting point after cutting (see „Installation VentaSnap + adhesion“).

Put both VENTAFLEX® air ducts up to contact and spread the glue with pressure by moving the ducts back and forth.



Finally pull the VentaSnap clamps over the connecting joints and screw them together.

**For air ducts with a length of over 15 m it is necessary to install an expansion compensation.**



Installation of a tight connection  
between VENTAFLEX® air duct and  
rectangular ductwork


Adhesion with  
VENTAFLEX® Glue  
to make a tight  
connection




Also suitable as a  
connection with  
transition to the  
correct dimension for  
the HVAC systems




## Transition of the VENTAFLEX® air duct to the duct of another producer



## Cross section: Installation of the adhesion



Since the diameters of the ducts of other producers are very often similar to the ducts of the VENTAFLEX® system, absolutely tight connections can be produced uncomplicated. A fitted cut-out end cover – if requested – makes an optically clean completion.



**VENTAFLEX®**

More efficiency in air conduction

**VENTAFLEX GmbH & Co. KG**

Siemensstraße 46

D-48341 Altenberge

Fon +49 (0) 2505 – 938290

Fax +49 (0) 2505 – 93829 -10

[info@ventaflex.de](mailto:info@ventaflex.de)

[www.ventaflex.de](http://www.ventaflex.de)

